


# WARREN RUPP



## Model SB1-A Type 3

# SandPIPER®

### Operating Instructions, Service Manual and Repair Parts List

**HAZARD WARNING—POSSIBLE EXPLOSION**  
HAZARD can result if 1, 1, 1-Trichloroethane, Methylene Chloride or other Halogenated Hydrocarbon solvents are used in pressurized fluid systems having Aluminum or Galvanized wetted parts. Death, serious bodily injury and/or property damage could result. Consult with the factory if you have questions concerning Halogenated Hydrocarbon solvents.

#### PRINCIPLE OF OPERATION:

The SandPIPER pump is designed to be powered only by compressed air which alternately pressurizes the inner sides of the two diaphragm chambers while simultaneously exhausting the opposite inner chambers causing the diaphragms, which are connected by a shaft, to move endwise. Since air pressure is applied over the entire surface of the diaphragm which is forcing liquid to be discharged by its other side, the diaphragm is operating under a balanced condition during the discharge stroke. This allows the unit to be operated at discharge heads over 200 feet (61 meters) of water head.

Alternate pressurizing and exhausting of the diaphragm chamber is performed by an externally mounted, pilot operated, four way, spool type air distribution valve. When the spool is at one end of the valve body, inlet air pressure is connected to one diaphragm chamber and the other diaphragm chamber is connected to the exhaust. When the spool is removed to the opposite end of the valve body, the porting of chambers is reversed. The air distribution valve spool is moved from one end position to the other in the valve body by means of an internal pilot valve which alternately pressurizes the ends of the air distribution valve spool while simultaneously exhausting the other ends. The pilot valve is positively shifted at each end of the diaphragm stroke by the diaphragm plate's coming in contact with the end of the pilot valve spool and pushing it into position for shifting of the air distribution valve. The chambers are manifolded together with a suction and discharge check valve for each chamber to maintain flow in one direction through the pump.

#### INSTALLATION PROCEDURES:

Position the pump as close as possible to the source of the liquid to be pumped. Avoid long or undersize suction lines and use the minimum number of fittings.

For permanent installations involving rigid piping, install short flexible sections of hose between the pump and piping. This reduces strains and permits easier removal of the pump for service when required. At time of installation, inspect all external gasketed fasteners for looseness caused by gasket creep. Tighten loose fittings securely to prevent leakage.

#### AIR SUPPLY:

Do not connect the unit to air supply in excess of 125 PSI (8.61 bars). Install a shutoff valve in the air supply line to permit removal of the unit for servicing. When connecting an air supply of rigid piping, mount a section of flexible line to the pump to eliminate piping strain. In permanent installations, an air line filter is recommended. The weight of the air supply line and of the filter must be supported by some means other than the air valve cap. Failure to provide support may result in damage to the pump.

#### LUBRICATION:

A small amount of lightweight oil (max. SAE 10 wt.) poured into the air inlet daily is recommended to lubricate the air distribution valve. An air line filter and lubricator is recommended on permanent installations. The lubricator should be set at a rate of one drop of oil for every 20 SCFM (Standard Cubic Feet per Minute) (9.44 lit./sec.) of air being used. When using EPDM elastomers, use no oil in the system or chemical attack may occur.

#### OPERATION:

Your SandPIPER pump has been tested prior to shipment and is ready for use as received. It is completely self-priming and no initial filling with fluid is required.

If the unit is to be totally submerged, the air exhaust must be piped above liquid level to prevent the liquid and foreign material from entering the air distribution valve mechanism.

Open the inlet air valve at least one turn to allow sufficient cycling rate for the pump to prime (30 to 60 cycles per minute). After pumping starts, adjust the inlet air valve for the desired pumping capacity. When further opening of the inlet air valve increases cycling rate without increasing the flow rate, the pump is being starved of liquid due to suction limitations. Further opening of the air inlet valve will waste compressed air. Set the inlet air valve for lowest cycling rate that does not decrease flow rate for most efficient operation.

#### FREEZING OR ICING OF EXHAUST:

Icing of air exhaust can occur under certain conditions of temperature and humidity on compressed air power equipment. Icing is more likely to occur at high discharge pressures. Use of a Warren Rupp Extractor/Dryer should eliminate the problem.

#### AIR EXHAUST:

SandPIPER pumps can be submerged if the materials of construction are compatible with the liquid and the exhaust is piped above the liquid level. (See OPERATION, above.) Piping used for the exhaust should not be smaller than the 1" pipe size. Reduced pipe size can restrict the exhausted air and cause reduce pump performance.

**CAUTION:** If a diaphragm fails, the pumped product or fumes can enter the air side of the pump. This side is exhausted through the exhaust port (muffler).

When the product is a hazardous or toxic material, the exhaust should be piped to an appropriate area for safe disposition.


When the product source is at a higher level than the pump (flooded suction), the exhaust should be piped to a higher level than the product to prevent spills caused by siphoning.

#### MAINTENANCE AFTER USE:

**CAUTION:** Before maintenance or repair, shut off the compressed air line, bleed the pressure, and disconnect the air line from the pump. The discharge line may be pressurized and must be bled of its pressure. When the pump is used for toxic or aggressive fluids, it should be flushed clean prior to disassembly.

When the pump is used for materials that tend to settle out or transform from liquid to solid form, care must be taken after

## Model SB1-A Type 3 SandPIPER



Repair Parts shown in **bold face (darker)** type are more likely to need replacement after extended periods of normal use. They are readily available from most Warren Rupp distributors. The pump owner may prefer to maintain a limited inventory of these parts in his own stock to reduce repair downtime to a minimum.

**IMPORTANT:** When ordering repair parts always furnish pump model number, serial number and type number.

Delrin, Teflon, Viton and Hytrel are registered trademarks of E.I. DuPont.  
 Gylon is a registered trademark of Garlock, Inc.  
 Nylatron is a registered trademark of Polymer Corporation.  
 Rulon II is a registered trademark of Dixon Industries Corp.  
 Ruppilon and SandPIPER are registered trademarks of Warren Rupp Inc.  
 Ryton is a registered trademark of Phillips Chemical Company.  
 Valox is a registered trademark of General Electric Company.

## SB1-A Type 3 Repair Parts List

ITEM NO.	PART NO.	DESCRIPTION	RQD.	ITEM NO.	PART NO.	DESCRIPTION	RQD.
1	165-042-157	Cap, Valve Body (AL Center)	1	39	115-070-330	Foot Bracket (Dual Ported Only)	1
	165-042-551	Cap, Valve Body (CI Center)	1	40	780-027-025	Spring	1
2	360-058-360	Gasket, Valve Cap	1	41	706-013-330	Screw, Machine	4
3	170-063-330	Capscrew, Hex Head	1	42	350-002-360	Foot, Rubber	4
4	170-033-330	Capscrew, Hex Head	4	43	547-002-330	Nut, Stop	4
5	901-035-330	Washer, Flat (AL Center)	7	44	618-003-330	Plug, Pipe	3
	901-035-330	Washer, Flat (CI Center)	1	44A	618-003-330	Plug, Pipe	2
	900-005-330	Washer, Lock (CI Center)	6		618-003-110	Plug, Pipe	2
6	901-005-330	Washer, Flat	4		618-003-112	Plug, Pipe	2
7	542-001-330	Nut, Square	1	45	132-022-360	Bumper, Actuator	2
8	095-051-551	Body, Spool Valve	1	46	170-045-330	Capscrew, Hex Head	4
9	031-039-000	Sleeve & Spool Set	1	47	360-031-360	Gasket	4
10	165-038-356	Cap, End	2		360-031-363	Gasket	4
11	675-043-115	Ring, Retainer	2		360-031-364	Gasket	4
12	560-058-360	O-Ring	8		360-031-365	Gasket	4
13	360-057-360	Gasket	1		360-031-600	Gasket	4
14	095-066-000	Pilot Valve Assembly <sup>1</sup> (AL Center)	1	48	334-013-157	Flange, Porting	2
	095-067-000	Pilot Valve Assembly <sup>2</sup> (CI Center)	1		334-013-110	Flange, Porting	2
					334-013-112	Flange, Porting	2
15	360-056-360	Gasket	1		334-036-156	Flange, Porting (Dual Porting)	2
16	114-007-157	Bracket, Intermediate	1	49	171-010-330	Capscrew, Flanged	4
	114-012-010	Bracket, Intermediate	1	50	905-001-330	Washer, Taper	4
17	560-040-360	O-Ring	2	51	360-030-425	Gasket Manifold	2
18	675-040-360	Ring, Sealing (AL Center)	2		360-030-600	Gasket, Manifold	2
19	720-010-375	Seal, U-Cup	2	52	900-004-330	Washer, Lock	10
20	070-012-170	Bearing, Sleeve	2	53	170-075-330	Capscrew, Hex Head	6
21	685-039-120	Rod, Diaphragm	1	53A	170-075-330	Capscrew, Hex Head (Dual Ported)	3
22	901-012-180	Washer, Sealing	2		170-084-330	Capscrew, Hex Head (Dual Ported)	3
23	170-034-330	Capscrew, Hex Head	2	54	560-030-360	O-Ring (use with 612-023-110)	2
	170-059-110	Capscrew, Hex Head (S.S. Non-Overlay)	2		560-030-363	O-Ring (use with 612-023-110)	2
24	900-003-330	Washer, Lock (not used with 612-023-330)	2	55	530-018-000	Muffler	1
				56	286-015-604	Diaphragm, Overlay	2
25	612-023-330	Plate, Outer	2	57	050-008-356	Check Ball	4
	612-023-110	Plate, Outer	2		050-008-360	Check Ball	4
25A	612-067-110	Plate, Outer (Overlay & Viton w/Teflon Balls)	2		050-008-363	Check Ball	4
					050-008-365	Check Ball	4
25A	612-101-112	Plate, Outer	2		050-011-600	Check Ball	4
25B	171-011-110	Capscrew, Flat Head (Use with 612-067-110)	2	58	518-006-156	Manifold	1
					518-006-110	Manifold	1
25B	807-048-330	Stud (Use with 612-101-112)	2		518-006-112	Manifold	1
26	286-008-356	Diaphragm	2	59	722-026-580	Seat, Check Ball (use w ith Elast. Balls)	2
	286-008-360	Diaphragm	2			Seat, Discharge (use with Teflon Balls)	1
	286-008-363	Diaphragm	2	59A	722-024-110	Seat, Suction (use with Teflon Balls)	1
	286-008-364	Diaphragm	2			Seat, Check Ball	2
	286-008-365	Diaphragm	2	59B	722-025-110	Elbow (Top Ported)	2
	286-008-366	Diaphragm	2				
27	612-022-330	Plate, Inner Diaphragm	2	59C	722-047-112	Valve Body Assembly (Includes Items: 8, 9, 10, 11, 12 & 40)	1
28	132-019-360	Bumper	2	60	312-022-360	Label "IN"	1
29	196-043-157	Chamber, Inner (left side)	1			Label "OUT"	1
	196-084-010	Chamber, Inner (left side)	1		485-004-000	Name Plate	1
30	196-042-157	Chamber, Inner (right side)	1		485-005-000	Name Plate (AL Outer Chamber Only)	2
	196-090-010	Chamber, Inner (right side)	1		545-005-330	Nut, Hex (SS Only)	4
31	620-015-114	Plunger, Actuator	2		705-002-000	Drive Screw (AL Center)	4
32	560-001-360	O-Ring	2		705-003-330	Drive Screw (CI Center)	4
33	135-013-162	Bushing	2		705-001-330	Drive Screw (AL Outer Chamber only)	4
34	675-042-115	Ring, Retainer	2				
35	170-043-330	Capscrew, Hex Head (AL Center)	6				
	170-006-330	Capscrew, Hex Head (CI Center)	6				
36	196-012-157	Chamber, Outer	2				
	196-012-110	Chamber, Outer	2				
	196-012-112	Chamber, Outer	2				
37	170-029-330	Capscrew, Hex Head	16				
38	545-004-330	Nut, Hex	26				
39	115-071-330	Foot Bracket	1				

**Optional Item:**

- 808-008-000 Strainer (AL Only) 1
- <sup>1</sup> Available only in kit form. Order P/N 031-052-000 which also includes items no. 2, 13, 15, 31, & 71.
- <sup>2</sup> Available only in kit form. Order P/N 031-051-000 which also includes items no. 2, 13, 15, 31, & 71.

### MATERIAL CODES

The Material Code Is The Last 3 Digits Of The Part Number

000...Assembly, sub-assembly; and some purchased Items	148...Hardcoat Anodized Aluminum	335...Galvanized Steel	365...Neoprene Rubber	542...Nylon
010...Cast Iron	149...2024-T4 Aluminum	336...Zinc Plated Yellow Brass	Color coded: GREEN	544...Nylon Injection Molded
012...Powdered Metal	150...6061-T6 Aluminum	337...Silver Plated Steel	370...Butyl Rubber	550...Polyethylene
015...Ductile Iron	151...6063-T6 Aluminum	340...Nickel Plated	Color coded: BROWN	551...Polypropylene
020...Ferritic Malleable Iron	152...2024-T4 Aluminum (2023-T351)	342...Filled Nylon	371...Phillthane (Tultane)	552...Unfilled Polypropylene
025...Music Wire	154...Almag 35 Aluminum	356...Hytril	375...Fluorinated Nitrile	553...Unfilled Polypropylene
080...CarbonSteel AISI B-1112	155 or 156...356-T6 Aluminum	357...Rupplon (Urethane Rubber)	378...High density Polypropylene	555...Polyvinyl Chloride
100...Alloy 20	157...Die Cast Aluminum Alloy #380	Color coded: PURPLE	405...Cellulose Fibre	570...Rulon II
110...Alloy Type 316 Stainless Steel	158...Aluminum Alloy SR-319	358...Rupplon (Urethane Rubber)	408...Cork and Neoprene	580...Ryton
111...Alloy Type 316 Stainless Steel (Electro Polished)	159...Anodized Aluminum	Color coded: PURPLE (Some Applications) (Compression Mold)	425...Compressed Fibre	590...Valox
112...Alloy "C"	162...Brass, Yellow, Screw Machine Stock	359...Urethane Rubber	426...Blue Gard	591...Nylatron G-S
113...Alloy Type 316 Stainless Steel (Hand Polished)	165...Cast Bronze, 85-5-5-5	360...Buna-N Rubber	440...Vegetable Fibre	592...Nylatron NSB
114...303 Stainless Steel	166...Bronze SAE 660	Color coded: RED	465...Fibre	600...Teflon (virgin material)
115...302/304 Stainless Steel	170...Bronze, Bearing Type, Oil Impregnated	361...Buna-N	500...Delrin 500	601...Teflon (Bronze and moly filled)
117...440-C Stainless Steel (Martensitic)	180...Copper Alloy	363...Viton (Fluorel)	501...Delrin 570	602...Filled Teflon
120...416 Stainless Steel (Wrought Martensitic)	310...Kynar Coated	Color coded: YELLOW	505...Acrylic Resin Plastic	603...Blue Gylon
	330...Zinc Plated Steel	364...E.P.D.M. Rubber	520...Injection Molded	604...Teflon
	331...Chrome Plated Steel	Color coded: BLUE	PVDF Natural Color	606...Teflon
	332...Electroless Nickel Plated		540...Nylon	610...Teflon Encapsulated Silicon
			541...Nylon	611...Teflon Encapsulated Viton

each use or during idle time to remove them and flush the pump as required to prevent damage.

In freezing temperatures the pump must be completely drained when idle.

### SERVICE INSTRUCTIONS: TROUBLE SHOOTING

#### 1. Pump will not cycle

A. Check to make sure the unit has enough pressure to operate and that the air inlet valve is open.

B. Check the discharge line to insure that the discharge line is neither closed nor blocked.

C. If the spool in the air distribution valve is not shifting, check the main spool. It must slide freely.

D. Excessive air leakage in the pump can prevent cycling. This condition will be evident. Air leakage into the discharge line indicates a ruptured diaphragm. Air leakage from the exhaust port indicates leakage in the air distribution valve. See further service instructions.

E. Blockage in the liquid chamber can impede movement of diaphragm.

#### 2. Pump cycles but will not pump

A. Suction side of pump pulling in air. Check the suction line for air leaks and be sure that the end of the suction line is submerged. Check flange bolting. Check valve flanges and manifold to chamber flange joints.

B. Make certain the suction line or strainer is not plugged. Restriction at the suction is indicated by a high vacuum reading when a vacuum gauge is installed in the suction line.

C. Check valves may not be seating properly. To check, remove the suction line and cover the suction port with your hand. If the unit does not pull a good suction (vacuum), the check valves should be inspected for proper seating.

D. Static suction lift may be too high. Priming can be improved by elevating the suction and discharge lines higher than the check valves and pouring liquid into the unit through the suction inlet. When priming at high suction lifts or with long suction lines operate the pump at maximum cycle rate.

#### 3. Low performance

A. Capacity is reduced as the discharge pressure increases, as indicated on the performance curve. Performance capability varies with available inlet air supply. Check air pressure at the pump inlet when the pump is operating to make certain that adequate air supply is maintained.

B. Check vacuum at the pump suction. Capacity is reduced as vacuum increases. Reduced flow rate due to starved suction will be evident when cycle rate can be varied without change in capacity. This condition will be more prevalent when pumping viscous liquids. When pumping thick, heavy materials the suction line must be kept as large in diameter and as short as possible, to keep suction loss minimal.

C. Low flow rate and slow cycling rate indicate restricted flow through the discharge line. Low flow rate and fast cycling rate indicate restriction in the suction line or air leakage into suction.

D. Unstable cycling indicates improper check valve seating on one chamber. This condition is confirmed when unstable cycling repeats consistently on alternate exhausts. Cycling that is not consistently unstable may indicate partial exhaust restriction due to freezing and thawing of exhaust air. Use of the Warren Rupp Extractor/Dryer should solve this problem.

### CHECK VALVE SERVICING:

Need for inspection or service is usually indicated by poor priming, unstable cycling, reduced performance or the pump's cycling but not pumping.

Remove the six flange bolts securing the inlet and outlet flanges to the manifold. Inspect the surfaces of both check valve and seat for wear or damage that could prevent proper sealing. If pump is to prime properly, valves must seat air tight.

### DIAPHRAGM SERVICING:

Remove the four bolts securing the manifold flange to the chamber. Remove the eight nuts securing the outer diaphragm chamber flange and remove the chamber. Loosen the capscrew securing the diaphragm and plate to the rod by leaving the diaphragm engaged with the capscrews around the outer flange, preventing rotation of the rod. **DO NOT USE A WRENCH ON THE DIAPHRAGM ROD. FLAWS ON THE SURFACE MAY DAMAGE BEARINGS AND SEAL.**

During reassembly make certain that the rubber bumper is on the rod on each side. Install the diaphragm with the natural bulge outward as indicated on the diaphragm. Install the heavier

plate on the outside of the diaphragm and make certain that the large radius side of both plates are toward the diaphragm. Place the sealing washer between the inner diaphragm plate and the end of the rod. Tighten the capscrew to approximately 25 ft. lbs. (33.9 Newton meters). Torque while allowing diaphragm to turn freely with plates. Use a wrench on the capscrew of the opposite side to keep the rod from rotating. If the opposite chamber is assembled, the rod need not be held.

When reassembling the outer chambers and the manifold, the bolts securing the manifold flange to the chamber should be snugged prior to tightening the chamber bolts, to insure that the chamber port flange is square with the manifold flange. Finish tightening the manifold flange bolts after chamber bolting is secured.

### AIR DISTRIBUTION VALVE SERVICING:

The spool and sleeve are rust and corrosion resistant brass and hardened stainless steel. The spool is closely sized to the sleeve and should slide freely. Accumulation of dirt and oils may prevent the pump from cycling. Remove the valve body from the center pump housing, remove the end caps, and push the spool out of the sleeve. Wash the parts in cleaning solvent or kerosene, and check the spool and sleeve for possible roughness, nicks or scratches. Use a fine stone or crocus cloth to carefully remove any irregular marks on the surfaces. When the spool slides freely on the sleeve, coat the parts with light oil and reassemble. The four capscrews inserted through the valve body cap to hold the air valve to the intermediate section should be torqued to 150 in./lbs. (16.9 Newton meters).

### PILOT VALVE SERVICING:

This assembly is reached by removing the air distribution valve body from the pump and lifting the pilot valve body out of the intermediate housing.

When reinserting an externally serviceable pilot valve, push both plungers out of the path of the pilot valve so that they and the pilot valve are not damaged.

### PILOT VALVE ACTUATOR SERVICING:

The bushings for the pilot valve actuators are pressed into the intermediate bracket from the outside. The plunger may be removed for inspection or replacement from the inside by removing the air distribution valve body and the pilot valve body from the pump. The plungers should be visible as you look into the intermediate from the top. Depending on their position, you may find it necessary to use a fine piece of wire to pull them out.

Under rare circumstances, it may become necessary to replace the o-ring seal. The bushing can be pushed through the inner chamber removing the outer chamber assembly to reach the bushing.

### WARRANTY:

This unit is guaranteed for a period of one year against defective material and workmanship.

**BEFORE PUMP OPERATION** all external gasketed fasteners must be inspected for looseness caused by gasket creep after leaving the factory. Retorque loose fasteners to insure against leakage. Follow recommended torques where called out. (A card is attached to each new pump stating this fact.)

## WARNING!

**TAKE ACTION TO PREVENT STATIC SPARKING. FIRE OR EXPLOSION CAN RESULT, especially when handling flammable liquids. The pump, piping, valves, containers or other miscellaneous equipment must be grounded.**

PRINTED IN U.S.A.

Copyright© 1992 Warren Rupp, Inc. All rights reserved.

WARREN RUPP, INC. • A Unit of IDEX Corporation